

RNA-seq解析パイプライン： Transcript-based pipeline

Shuji Shigenobu

重信 秀治


基礎生物学研究所
生物機能解析センター




Two Basic Pipelines

- ▶ Choice of reference
 - ▶ **Genome** – standard for genome-known species
 - ▶ **Transcript** – the only way for genome-unknown species
 - can be used for genome-known species

RNA-seq workflow with reference genome




RNA-seq workflow **without** reference genome



1. **Build** reference
2. **Characterize** reference

A Pipeline: Transcript-based




Mapping – alignment software

- ▶ For mapping reads onto transcript reference
short read mapper (unspliced read aligner) is used

- ▶ **Bowtie2** – basic mapping to reference sequence

<http://bowtie-bio.sourceforge.net/bowtie2/index.shtml>



bowtie-bio.sourceforge.net/bowtie2/index.shtml

BOW TIE **Bowtie 2**
Fast and sensitive read alignment

JOHNS HOPKINS UNIVERSITY

Bowtie 2 is an ultrafast and memory-efficient tool for aligning sequencing reads to long reference sequences. It is particularly good at aligning reads of about 50 up to 100s or 1,000s of characters, and particularly good at aligning to relatively long (e.g. mammalian) genomes. Bowtie 2 indexes the genome with an FM Index to keep its memory footprint small: for the human genome, its memory footprint is typically around 3.2 GB. Bowtie 2 supports gapped, local, and paired-end alignment modes.

OSI certified

Hiring Postdocs

- The [Langmead](#) and [Salzberg](#) labs currently have open positions for postdoctoral researchers. See [the posting](#) and please apply if you're interested in working with either or both of us.

Version 2.1.0 - February 21, 2013

- Improved multithreading support so that Bowtie 2 now uses native Windows threads when compiled on Windows and uses a faster mutex. Threading performance should improve on all platforms.
- Improved support for building 64-bit binaries for Windows x64 platforms.
- Bowtie 2 uses a lightweight mutex by default.
- Test option `--no-spin` is no longer available. However bowtie2 can always be recompiled with `EXTRA_FLAGS="-DNO_SPINLOCK"` in order to drop the default spinlock usage.

Version 2.0.6 - January 27, 2013

- Fixed issue whereby spurious output would be written in `--no-unal` mode.
- Fixed issue whereby multiple input files combined with `--reorder` would cause truncated output and a memory spike.
- Fixed spinlock datatype for Win64 API (LLP64 data model) which made it crash when compiled under Windows 7 x64.
- Fixed bowtie2 wrapper to handle filename/paths operations in a more platform independent manner.
- Added pthread as a default library option under cygwin, and pthreadGC for MinGW.
- Fixed some minor issues that made MinGW compilation fail.

Version 2.0.5 - January 4, 2013

- Fixed an issue that would cause excessive memory allocation when aligning to very repetitive genomes.
- Fixed an issue that would cause a pseudo-randomness-related assert to be thrown in debug mode under rare circumstances.

Version 2.0.4 - December 17, 2012

- Fixed issue whereby `--un`, `--ai`, `--un-conc`, and `--ai-conc` options would incorrectly suppress SAM output.

Site Map

- [Home](#)
- [News archive](#)
- [Manual](#)
- [Getting started](#)
- [Frequently Asked Questions](#)
- [Tools that use Bowtie](#)

Latest Release

Bowtie2 2.1.0 2/21/13

Please cite: Langmead B, Salzberg S. *Fast gapped-read alignment with Bowtie 2. Nature Methods. 2012; 9:357-359.*

Related Tools

- [Bowtie](#): Ultrafast short read alignment
- [Crossbow](#): Genotyping, cloud computing
- [Myrna](#): Cloud, differential gene expression
- [Tophat](#): RNA-Seq splice junction mapper
- [Cufflinks](#): Isoform assembly, quantitation

Indexes

H. sapiens, UCSC hg18	3.5 GB
or: part 1 (1.5 GB), part 2 (651 MB), part 3 (1.5 GB)	
H. sapiens, UCSC hg19	3.5 GB
or: part 1 (1.5 GB), part 2 (650 MB), part 3 (1.5 GB)	
mm10	3.2 GB
or: part 1 (1.3 GB), part 2 (593 MB), part 3 (1.3 GB)	
R. norvegicus, UCSC rn4	3.1 GB
or: part 1 (1.3 GB), part 2 (580 MB), part 3 (1.3 GB)	

Some unzip programs cannot handle archives >2 GB. If you have problems downloading or unzipping a >2 GB index, try downloading in parts.

<http://bowtie-bio.sourceforge.net/bowtie2/index.shtml>

- Updated manual's discussion of the `-i` and `-x` options to mention that setting them farther apart makes Bowtie 2 slower.
- Renamed `COPYING` to `LICENSE` and created a `README` to be GitHub-friendly.

bowtie2

Bowtie is an ultrafast, memory-efficient short read aligner.

<http://bowtie-bio.sourceforge.net/bowtie2/index.shtml>

(example)

```
$ bowtie2 -x transcript.fa -U reads.fq -a -S out.sam
```

► Output

► Alignment in SAM format : **out.sam**

(ex1) Let's Try Bowtie2

Align 75-bp Illumina reads with a transcript reference using Bowtie2.

Prepare reads and reference genome

Sequences for this exercise are stored in `~/data/SS/`.

IlluminaReads1.fq – Illumina reads in fastq format
 minimouse_mRNA.fa – a set of transcript sequences

Build index of reference sequence

```
$bowtie2-build minimouse mRNA.fa myref
```

Align reads with reference

```
$bowtie2 -x myref -U IlluminaReads1.fq -a -S out.sam
```

Evaluation of mapping results



- ▶ Evaluation of SAM/BAM file
- ▶ Check statistics
- ▶ Visualization

(example)

```
$ samtools view bowtieout.bam
```

[illegible]

Count Reads by Transcript/gene



- ▶ The simplest way: just count reads by contig.

But...

- ▶ Mapping ambiguity should be taken into consideration.

Estimate Abundance

▶ **Multimapping issues**

- ▶ Isoforms
- ▶ Very similar paralogs
- ▶ Repetitive sequences
- ▶ => cannot align reads uniquely
- ▶ Mapping ambiguity should be taken into consideration.



- ▶ Critical for RNA-seq de novo analysis
- ▶ Software: RSEM and eXpress (EM algorithm)

eXpress

eXpress is a streaming tool for quantifying the abundances of a set of target sequences from sampled subsequences.

<http://bio.math.berkeley.edu/eXpress/>

(example)

```
$ express transcripts.fasta hits.bam
```

► Output

- Count estimation table: **results.xprs**

The screenshot shows the eXpress website homepage. The header features the eXpress logo (a stylized 'X' with 'e' and 'press' inside) and the tagline "Streaming quantification for high-throughput sequencing". A Google Custom Search bar is located on the right. Below the header is a navigation menu with links: Home, About, Download, Getting Started, Source, Manual, and FAQ. The main content area is divided into three columns. The left column, titled "Home", contains a "News" section with two entries: "02.09.2014 • eXpress Mac 1.5.1 binary updated." and "12.08.2013 • eXpress now available in the cloud with eXpress-D!". The middle column, titled "Download", lists the "Current Release" as "eXpress 1.5.0" with links for "Mac OS X (64-bit) Binary", "Linux (64-bit) Binary", "Windows (64-bit) Binary", and "Source". It also lists "Previous Versions" with a "View All" link. The right column, titled "Support", includes an email address "ask.xprs@gmail.com" and a "wiki" link on GitHub.

<http://bio.math.berkeley.edu/eXpress/index.html>

(ex1) Let's Try eXpress

Align 75-bp Illumina reads with a transcript reference using Bowtie2.

Prepare alignments and reference genome

Sequences for this exercise are stored in `~/data/SS/`.

IlluminaReads1.fq – Illumina reads in fastq format
out.sam – this file should be generated in the previous bowtie practice

Run eXpress

```
$ express minimouse_mRNA.fa out.sam
```

Output : results.xprs, params.xprs

eXpress: output

results.xprs

	A	B	C	D	E	F	G	H	I	J	K	L	M	N
1	bundle_id	target_id	length	eff_length	tot_counts	uniq_counts	est_counts	eff_counts	ambig_distr_alpha	ambig_distr_beta	fpkm	fpkm_conf_low	fpkm_conf_high	solvable
2	1	m.245853	621	398.1	807	15	86.2	134.4	9.83E+01	9.96E+02	2.34E+01	1.88E+01	2.80E+01	T
3	1	m.245856	660	442.0	991	199	919.8	1373.4	5.53E+01	5.46E+00	2.25E+02	2.12E+02	2.38E+02	T
4	2	m.42076	1959	1591.7	156	156	156.0	192.0	0.00E+00	0.00E+00	1.06E+01	1.06E+01	1.06E+01	T
5	3	m.60782	291	83.0	12	12	12.0	42.1	0.00E+00	0.00E+00	1.57E+01	1.57E+01	1.57E+01	T
6	4	m.158451	282	64.5	0	0	0.0	0.0	0	0	0.00E+00	0.00E+00	0.00E+00	T
7	5	m.337354	219	39.4	0	0	0.0	0.0	0	0	0.00E+00	0.00E+00	0.00E+00	T
8	6	m.338934	261	82.3	0	0	0.0	0.0	0	0	0.00E+00	0.00E+00	0.00E+00	T
9	7	m.5973	822	719.9	4	4	4.0	4.6	0.00E+00	0.00E+00	6.01E-01	6.01E-01	6.01E-01	T
10	8	m.337793	219	38.7	0	0	0.0	0.0	0	0	0.00E+00	0.00E+00	0.00E+00	T
11	9	m.340910	210	40.5	0	0	0.0	0.0	0	0	0.00E+00	0.00E+00	0.00E+00	T
12	10	m.289784	3177	2521.4	350	350	350.0	441.0	0.00E+00	0.00E+00	1.50E+01	1.50E+01	1.50E+01	T
13	11	m.248666	240	61.8	1	1	1.0	3.9	0.00E+00	0.00E+00	1.75E+00	1.75E+00	1.75E+00	T
14	12	m.90727	240	55.7	13	13	13.0	56.1	0.00E+00	0.00E+00	2.53E+01	2.53E+01	2.53E+01	T
15	13	m.338727	216	48.1	0	0	0.0	0.0	0	0	0.00E+00	0.00E+00	0.00E+00	T
16	14	m.123519	225	43.2	0	0	0.0	0.0	0	0	0.00E+00	0.00E+00	0.00E+00	T
17	15	m.328661	251	50.8	1	1	1.0	4.9	0.00E+00	0.00E+00	2.13E+00	2.13E+00	2.13E+00	T
18	16	m.26062	642	356.1	1	1	1.0	1.8	0.00E+00	0.00E+00	3.04E-01	3.04E-01	3.04E-01	T
19	17	m.1295	240	53.6	0	0	0.0	0.0	0	0	0.00E+00	0.00E+00	0.00E+00	T
20	18	m.307626	201	220.2	4	3	3.0	2.7	8.33E+00	4.07E+04	1.47E+00	1.46E+00	1.49E+00	T
21	18	m.307625	204	35.7	301	300	301.0	1718.3	1.02E+01	1.02E+01	9.12E+02	9.05E+02	9.18E+02	T
22	19	m.49789	237	51.9	3	3	3.0	13.7	0.00E+00	0.00E+00	6.26E+00	6.26E+00	6.26E+00	T
23	20	m.33508	162	151.3	1	1	1.0	1.1	0.00E+00	0.00E+00	7.15E-01	7.15E-01	7.15E-01	T
24	21	m.109341	183	286.3	2	2	2.0	1.3	0.00E+00	0.00E+00	7.56E-01	7.56E-01	7.56E-01	T
25	22	m.331919	564	277.3	0	0	0.0	0.0	0	0	0.00E+00	0.00E+00	0.00E+00	T
26	23	m.23766	303	98.5	3	3	3.0	9.2	0.00E+00	0.00E+00	3.30E+00	3.30E+00	3.30E+00	T
27	24	m.246777	1149	1152.1	631	29	202.5	202.0	1.58E+02	3.90E+02	1.90E+01	1.65E+01	2.15E+01	T
28	24	m.246852	1323	1315.4	761	156	588.8	592.2	1.22E+02	4.85E+01	4.84E+01	4.50E+01	5.19E+01	T
29	24	m.246633	207	31.8	10	4	5.7	37.1	1.29E+04	3.27E+04	1.94E+01	1.05E+01	2.82E+01	T
30	24	m.246662	192	200.4	6	3	3.0	2.9	1.20E+01	3.22E+03	1.63E+00	1.51E+00	1.74E+00	T
31	25	m.99743	1641	1387.9	470	470	470.0	555.7	0.00E+00	0.00E+00	3.66E+01	3.66E+01	3.66E+01	T
32	26	m.335620	234	58.9	0	0	0.0	0.0	0	0	0.00E+00	0.00E+00	0.00E+00	T
33	27	m.16882	528	297.5	14	14	14.0	24.9	0.00E+00	0.00E+00	5.09E+00	5.09E+00	5.09E+00	T
34	28	m.77438	255	81.4	9	9	9.0	28.2	0.00E+00	0.00E+00	1.20E+01	1.20E+01	1.20E+01	T
35	29	m.131505	450	263.2	18	11	15.8	27.1	8.87E+00	3.95E+00	6.51E+00	4.68E+00	8.35E+00	T
36	29	m.131517	170	195.9	6	0	1.8	1.5	8.17E+00	1.96E+01	9.74E-01	0.00E+00	2.46E+00	T
37	29	m.131504	705	528.2	15	14	14.4	19.2	6.53E+01	1.01E+02	2.95E+00	2.69E+00	3.21E+00	T

Table of counts

data import


diagnostics

normalization



DE testing

evaluation

List of DE gene



Diagnostics: Scatter plot & MA plot



edgeR

- ▶ A Bioconductor package for differential expression analysis of digital gene expression data
- ▶ **Model:** An over dispersed Poisson model, negative binomial (NB) model, is used
- ▶ **Normalization:** TMM method (trimmed mean of M values) to deal with composition effects
- ▶ **DE test:** exact test and generalized linear models (GLM)


edgeR

- ▶ input: count data (not RPKM)
- ▶ output: gene table with DE significance statistics (FDR)

(example)

```
$ R
> library(edgeR) #load edgeR library
> dat <- read.delim("count_data.txt", ...) #import count table to R
> group <- c(rep("M", 3), rep("H", 3)) #assign groups
> D <- DGEList(dat, group=group) #import data to edgeR
> D <- calcNormFactors(D) #normalization (TMM)
> D <- estimateCommonDisp(D) #estimate common dispersion
> D <- estimateTagwiseDisp(D, ...) #estimate tagwise dispersion
> de <- exactTest(D, pair=c("M", "H")) #DE test
> topTags(de)
Comparison of groups: H-M
      logConc    logFC      P.Value      FDR
AT5G48430 -15.36821 6.255498 9.919041e-12 2.600872e-07
AT5G31702 -15.88641 5.662522 3.637593e-10 4.083773e-06
AT3G55150 -17.01537 5.870635 4.672331e-10 4.083773e-06
...
```


RNA-seq analysis pipeline (*de novo* strategy)



de novo assemblers of RNA-seq

De novo assemblers use reads to assemble transcripts directly, which does not depend on a reference genome.

- ▶ Trinity
- ▶ Oases
- ▶ TransAbyss
- ▶ EBARDenovo
- ▶ ...



<http://trinityrnaseq.sourceforge.net/>

Trinity example

- ▶ Input: Illumina short reads in FASTQ | FASTA format
- ▶ Output: assembled contigs in FASTA format

```
# prepare input reads
$ cat *.R1.fastq > left_all.fq
$ cat *.R2.fastq > right_all.fq

# Run Trinity
$ Trinity --seqType fq --left left_all.fq --right right_all.fq --
CPU 8 --max_memory 20G
```

(Trinity is supported on only Linux)

optional

ORF prediction

- ▶ Special consideration in ORF prediction after de novo RNA-seq assembly
 - ▶ Sometimes partial: Start Met or terminal codon may be missing.
 - ▶ Ideally one ORF is present per contig, but erroneously joined contigs may include multiple ORFs.
 - ▶ Possible frame shifts.
 - ▶ Frame shifts do not occur so often in Illumina, while it happens very frequently in 454 and IonProton.

optional

Functional Annotation of Predicted ORFs

▶ BLAST

- ▶ NCBI NR (or UniProt)
- ▶ species of interest (model organisms, close relatives etc)
- ▶ specific DB (SwissProt, rRNA DB, CEGMA etc)
- ▶ self (assembly v.s. assembly)

▶ Motif search

- ▶ Pfam, SignalP etc.

▶ Ortholog analysis

- ▶ vs model organism
- ▶ ortholog database (OrthoDB, eggNOG, OrthoMCL etc)
- ▶ close relatives

▶ Gene Ontology term assignment

optional

Quick annotation by BLASTX

▶ Query: assembled contigs

(nucleotide sequences in multi-fasta format)

▶ DB: Protein sequences of a model organism

Format DB

```
$ makeblastdb -in protein.fa -dbtype prot
```

Search

```
$ blastx -query trinity_contigs -db protein.fa \  
-num_threads 8 -evaluate 1.0e-8 -outfmt 0 > blastxout.txt
```

optional

Let's try BLASTX

- ▶ Query: minimouse_mRNA.fa
- ▶ DB: human.protein.faa (human RefSeq protein)

1. Format DB

```
$ makeblastdb -in human.protein.faa -dbtype prot -parse_seqids
```

2. Search

```
$ blastx -query minimouse_mRNA.fa -db human.protein.faa \  
-num_threads 8 -evaluate 1.0e-8 -outfmt 0 > blastxout.txt
```

```
$ blastx -query minimouse_mRNA.fa -db human.protein.faa \  
-num_threads 8 -evaluate 1.0e-8 -outfmt 7 > blastxout.tab
```